
Index

A

activating

- new system 92
- wireless communications 183

activation code 89

adjusting contrast

- Administration Terminal 72
- contrast level 72

Administration log

- checking recent alarms 130
- checking repetitions 130
- checking time 130
- entering 129
- erasing 129, 131
- event messages 129
- recording messages 129

Administration password

- changing 85
- default 85
- erasing 86
- recording 86
- unauthorized access 85

Administration programming

- changing the password 85
- ending a session 73
- entering a password 72
- entering a session 72
- Master Registration 112
- radio loss handling 108
- setting the date 83
- setting the time 82

system administrator 85

Transfer on Radio loss 108

Administration Terminal

- alarm messages 73
- connection to Controller 73
- contrast 72
- device 75
- dialpad buttons 70
- display 70
- display buttons 70
- displaying system date 83
- displaying system time 82
- exception message 156
- Feature button 70
- Maintenance programming 117
- navigation buttons 71
- operating 72
- port connection 73
- registering portables 111
- Release button 70
- replacing 154
- system time and date 82
- troubleshooting 164

alarm messages

- Event/Alarm log 126
- recording 73
- reporting 73
- system 73

alarms

- reporting 131
- troubleshooting 171

- antenna
 - external 33
 - outdoor external 35
- antenna setting
 - System Reevaluation 132
- antenna type
 - changing 79
 - displaying 79
 - running reevaluation 79
 - setting 79

B

- Base Station
 - adding 141
 - and CMCC 74
 - and CMRC 74
 - and radio coverage 142
 - cabling 25
 - cabling to RPI 25
 - changing configuration 133
 - clearance 14
 - connections 74
 - deployment 141
 - device 75
 - increasing coverage area 141
 - installing 12
 - local power 30
 - mounting 14
 - moving 141–143
 - number in cell 141
 - plug-top power supply 12
 - polarity 28
 - present on system 74
 - registering portables 111
 - replacing a defective 143
 - software 65
 - status 74
 - System Reevaluation 132
 - TCM port 75
 - troubleshooting 165
 - wiring length 12
- Base Station address
 - adding to site plan 97
- BIX connector board 26

- BNC connectors 35
- button caps 71
- B03 gain values
 - changing 76
 - digital signal paths 76
 - displaying 76
 - entering a new 76
 - negative 76
 - positive 76
 - telephony data 76

C

- cabling
 - from Base Station to RPI 25
- card LED behavior 163
- card status
 - checking card type 120
 - checking state 120
 - idle 74
 - Meridian 1 system 99
 - verifying 74
- cards
 - installed on system 74
 - troubleshooting 161
- cell assignment
 - and radios 79
 - displaying 98
 - floor plan 96
 - identifying for a radio 98
 - not assigned 98
 - viewing 97
- cell boundary value
 - and RSSI 96
 - high-power mode 96
 - low-power mode 96
- cell center 96
- changing
 - Installer password 84
 - system date 83
 - system time 82
- changing defaults
 - B03 gain values 75, 76
 - Delay to Dial 75
 - side tone 75, 77

- telephony data 75
- changing the LID 80
- CMCC
 - checking status 74
 - connecting a Base Station 74
 - replacing 152
- CMLC
 - adding to system 144–145
 - checking status 74
- CMRC
 - adding to system 144–145
 - checking status 74
 - connecting a Base Station 74
- CO line interface 184
- coaxial cable
 - and external antenna 33
- code
 - UTAM activation 66, 89
- coldstart 65
- Configuration programming
 - antenna type 79
 - B03 gain values 76
 - cell assignments 97
 - changing Installer password 84
 - changing LID 81
 - Delay to Dial 75
 - ending a session 73
 - entering a session 72
 - portable credits 114
 - radio cell assignment 98
 - Show cell 98
 - software codes 92, 139
 - System Reevaluation 136
 - telephony data 75, 77
- configuring
 - a terminal number (TN) 101
 - Meridian 1 system 99
- configuring portables
 - with X11 releases 100
- contrast
 - adjusting 72
- critical point 96

D

- default
 - Administration password 85
 - Installer password 84
 - Registration password 86
- default password
 - Administration programming 72
 - Configuration programming 72
- Delay to Dial
 - changing default 75
 - delay ranges 75
 - programming 75
 - recording 75
- deployment 97
- deregistering
 - wireless terminal number (WTN) 114
- device
 - Administration Terminal 75
 - Base Station 75
 - RAD 75
- dialpad buttons
 - entering LID values 81
 - feature codes 70
- digital signal paths
 - changing 76
- directed RSSI
 - measuring for portable 113
- disabled system
 - activating 140
- disabling
 - wireless system 97
- display buttons
 - options 70
- displaying
 - antenna type 79
 - B03 gain values 76
 - system LID 81
 - telephony data 76
- downloading software 65
- dropping calls 107

E

- entering
 - Administration password 85

- LID values 81
- portable credits 92
- UTAM activation codes 92
- entering password
 - Administration programming 72
 - Configuration programming 72
 - Installer programming 72
- erasing system data 67
- event
 - Administration log 129
 - severity number 126, 129
- event messages
 - reporting 131
 - troubleshooting 177
- Event/Alarm log
 - checking recent alarms 127
 - checking repetitions 128
 - checking time 127
 - entering 127
 - erasing events 126
 - erasing the log 128
 - recording messages 126
- exception
 - nonrecoverable inconsistency 157
 - recoverable inconsistency 156
- expansion cards
 - adding 144–145
 - replacing 148
- external antenna
 - BNC connectors 35
 - mounting 33
 - specifying on system 79
- F**
- FCC
 - certified equipment 185
 - telecom compliance 186
- Feature button
 - and exceptions 156
- feature codes
 - entering 70
- Federal Communications Commission
 - See* FCC
- floor plan

- cell assignments 96
- cell center 96
- critical point 96

G

- generating
 - LID 80

H

- hand-off
 - radio coverage area 95
- hardware
 - installing 11
- hearing aids
 - and portable telephones 188
- high-power mode
 - cell boundary value 96

I

- idle cards 74
- initialization 65
- initializing
 - the system 65
- Installer password
 - changing 84
 - default 84
 - recording 84
 - unauthorized access 84
- Installer programming
 - entering a session 72
 - entering password 72
 - menus 72
 - see also* Configuration programming
- installing
 - Base Stations 12
 - external antenna 33
 - hardware 11
 - lightning surge arrestor 33
 - outdoor external antenna 35
 - plug-top power supply 12
 - RPI unit 23
- interference 187
- invalid code
 - UTAM 93
- IPE card slots

- disabling 146
- L**
- LD 97
 - class of service 100
- LED behavior
 - cards 163
 - system 162
- LID
 - changing 80
 - default 80
 - setting 80
- LID values
 - entering 81
 - valid 81
- lightning surge arrestor
 - installing 33, 184
- local power
 - Base Station 30
- logical identifier (LID)
 - see* LID
- low-power mode
 - cell boundary value 96
- M**
- maintenance
 - Administration Terminal 70
- maintenance cable 151
- Maintenance programming
 - Administration log 129
 - alarm messages 126
 - card states 121
 - card status 120
 - checking system status 118
 - checking system version 118
 - displaying release number 118
 - displaying software version 118
 - Event/Alarm log 126, 127
 - features 117
 - system states 119
 - TCM status 124
 - WTN status 122
- maintenance session
 - verifying cards 74
- Master Registration
 - default 112
 - disabling 112
 - enabling 112
- MDF wiring 74
- Memory Reset
 - entering code 66
 - erasing system data 67
 - reinitializing system 66
- Meridian 1
 - card maintenance 116
 - card status 99
 - extended features 100
 - LD 97 99
 - privacy feature 100
 - ringer default 99
- Meridian 1 system
 - configuring 99
- mobility data
 - assigning cells 79
 - programming 79
- monitoring
 - wireless communication 89
- mounting
 - a Base Station 14
 - an RPI 23
 - external antenna 33
 - plug-top power supply 30
- N**
- navigation buttons
 - arrows 71
 - searching 71
- new system
 - activating 92
- O**
- operating
 - Administration Terminal 72
- outdoor external antenna
 - installing 35
- P**
- password
 - Administration 85
 - Installer 84

- Registration 86
- PC Interface Card
 - installing 39
- plug-top power supply
 - connector 31
 - installing 12
 - mounting 30
- polarity 28
- port address
 - and cards 74
- Portable Credit Code
 - recording 92
- portable credits
 - adding 138
 - entering 92
 - number available 114
 - obtaining 138
 - verifying 114
- portable telephone
 - and changing LID 80
 - and credit codes 89
 - configuring using X11 releases 100
 - credits available 111
 - displaying RSSI 95
 - LID 80
 - losing a link 107
 - making calls 113
 - maximum on system 89
 - measuring directed RSSI 113
 - receiving calls 113
 - registration 111
 - Registration password 86
 - replacing 113, 154
 - side tone 77
 - system time and date 82
 - Transfer on Radio loss 107
 - troubleshooting 168
- power interruption
 - disabled system 140
 - troubleshooting 161
- power supply connector
 - position of 30
- programming
 - Feature button 70

- Installer 72
- mobility data 79
- overview 181
- Release button 70
- system date 83
- system time 82
- system time and date 82
- telephony data 75
- the system 69

R

RAD

- device 75
- replacing 154
- troubleshooting 170

radio

- cell assignment 98

radio assignments

- viewing 97

radio coverage

- and hand-off 95

radio credits

- adding 139
- software codes 139
- UTAM Activation Code 139
- verifying 170

radio frequency interference 187

radio loss handling

- programming a default 108
- transferring calls 108

radios

- assigning a cell 97
- assigning cells 79
- identifying 79

reevaluation

- see* System Reevaluation

registering

- portable telephones 89

registering portables

- and portable credits 111

registration 112

Registration password

- changing 86
- default 86

- entering a new 86
- recording 87
- unauthorized access 87
- Regression Code 154
- reinitializing
 - Memory Reset 66
- Release button 70
- relocating
 - and reevaluation 145
 - existing system 145
- remote power interconnect unit
 - see* RPI
- REN
 - terminal device 188
- repair facility 188
- replacing
 - CMCC 152
 - expansion cards 148
 - portable telephone 154
 - RAD 154
 - ROM card 149
 - RPI power unit 153
 - RPI unit 152
- reporting
 - alarms 131
 - events 131
- ringer equivalence number
 - See* REN
- ROM card
 - replacing 149
 - System Reevaluation 149
- RPI
 - and polarity 28
 - BIX connector board 26
 - cabling to Base Station 25
 - DC backup power 29
 - installing 17–23
 - mounting 23
 - output connections 27
 - powering down 28
 - powering up 28
 - replacing 152
 - troubleshooting 166
 - upgrading 21, 29

- wiring 25
- RPI configurations
 - large installations 19
 - small installations 18
- RPI power 74
- RPI power unit
 - replacing 153
- RSSI
 - and cell boundary value 95
 - observing 95
- RSSI measurements 96
- S**
- searching
 - using navigation buttons 71
- severity number
 - and events 126, 129
- Show cell
 - viewing cell assignment 98
- side tone
 - changing 77
 - default 77
 - portable telephone 77
- software
 - Base Station 65
 - downloading 65
 - new installations 65
- software codes
 - radio credits 139
 - SSN 92
- SSN
 - displaying 92
 - recording 92
- state
 - idle cards 74
- system 85
 - alarm messages 73
 - and UTAM codes 66
 - Base Station location 75
 - cards installed 74
 - coldstart 65
 - initializing 65
 - LID 80
 - Memory Reset 65

- programming 69
- registering portables 89
- relocating 145
- startup 65
- system access
 - LID 80
- system coldstart 65
- system date 82
- system default
 - radio loss handling 108
- system initialization
 - description 65
 - exception 156
- system installation
 - verifying 95
- system LED
 - initializing expansion cards 146
- system LED behavior 162
- system LID
 - changing 81
 - displaying 81
- system programming
 - Administration Terminal 70
- system recovery
 - entering codes 154
 - Regression code 154
- System Reevaluation
 - and antenna settings 132
 - and Base Stations 132
 - canceling 135
 - changing configuration 133
 - disabling system 132
 - dropping calls 135
 - run times 135
 - running 133
 - scheduling 136
 - setting the date 137
 - setting the time 136
- system security number
 - see* SSN
- system startup
 - nonrecoverable inconsistency 157
 - recoverable inconsistency 156
- system states 119

- system time 82
- system time and date
 - when to reset 82

T

- TCM connections
 - and polarity 18
- TCM device states 125
- TCM port 75
- TCM status
 - checking device status 124
 - checking device types 124
 - device firmware 124
 - device software 124
 - displaying TCM 75
 - entering device number 124
- telephony data
 - B03 gain values 75, 76
 - changing defaults 75
 - defaults 75
 - Delay to Dial 75
 - programming 75
 - side tone 75, 77
- terminal number (TN)
 - configuring for portable 101
- Transfer on Radio loss
 - dropping calls 107
 - entering a number 108
 - losing a link 107
 - options 107
- troubleshooting 159–160

U

- upgrading an RPI 21, 29
- UTAM
 - codes 66
 - test 66
- UTAM Activation Code
 - entering 92
 - invalid code 93
 - recording 92
- UTAM activation code 89
- UTAM Inc.
 - monitoring wireless activity 89
- UTAM Recovery Code

- activating disabled system 140
- obtaining 140
- system on-line 140

V

- valid system LID 81
- verifying
 - card status 74

W

- wireless communication
 - activating 89
 - and UTAM Inc. 89
- wireless communications
 - approval 183
- wireless privacy
 - setting 103
- wireless system
 - deployment 97
 - disabling 97
- wireless terminal number (WTN)
 - checking status 122
 - deregistering 114
 - states 123
 - verifying 113
- wiring
 - an RPI 25

X

- X11 release 15-18
 - and CPND 105
- X11 release 19
 - and CPND 105
- X11 release 20B
 - and data blocks 106
 - printing features 104
 - printing new values 103
 - printing terminal numbers 104
 - printing values 103
- X11 releases
 - configuring portables 100
 - programming options 103
 - verifying configuration 100

